

User Guide





User Manual

Features	1
Know your Player	2
Package content:	
Layout and keys	
Connecting the earphones	
Battery	
Play mode	
Music format	
USB disk	
Keys Intro	3
How to change your earplug	4
Armband	4
ILLUSTRATIONS	5

NOTE:

1. **Do not try to disassemble the player body in any condition or the warranty will be invalid.**
2. **We recommended 3-4 hours of charging before use. The LED light will be turn off once it is fully charged.**
3. **The player will be automatically charged once connected via USB cable to the PC. (LED light will be on). Once the cable is disconnected, the player will enter the PLAY mode itself.**
4. **It is highly recommended that user should connect the USB cable with the player BEFORE plugging into the PC for charging. And pull off the USB cable AND the player TOGETHER from the PC when finished.**

Kanyon is a high-end water proof personal audio player. It provides not only the fantastic MP3 player functionality but also a best choice to be used in outdoors, specially water sport occasions. Kanyon has passed the severe test of IPx8 rating of under water test. It also implements the technique to oxidize colors on its aluminum body that gives the unit greater protection against accidental damage from either dropping or get rusted in water.

Kanyon is a portable lifestyle product for individual who appreciates design of simplicity of use.

Features

1. Support MP3/WMA music format
2. USB 2.0 flash drive
3. Rechargeable battery
4. 3 meters water depth for 3 hours, can meet IPx8 standard for both Kanyon and water proof earphone



Know your Player

1. Package content:



Kanyon



Water Proof Earphone and Ear buds set



User Manual








USB Cable



Armband set

2. Layout and keys



HOLD TO ADJUST VOLUME

QUICK TAP TO SKIP TRACKS



3. Connecting the earphones: insert the earphone audio pin into the player's water proof audio extension cable
4. Battery: the player uses built-in rechargeable-battery. You can recharge the battery via audio extension cable jack by connecting with the USB cable
5. Play mode: the system default mode for playing music is to repeat all songs.
6. Music Format: the system supports various music formats, including MP3 and WMA.
7. USB disk: the Kanyon supports USB 2.0, and is compatible with Windows 2000 or higher without any driver. It can also be used as a USB flash drive for your personal data.


Keys Intro

There are a total of only 4 keys on the Kanyon


1. Play/Pause/Stop:
 - Play: hold down the key until the LED light is on.
 - Pause: a short press will pause the music (LED blinks quickly)
 - Stop: a longer press will stop the music playing (LED light is off)
2. Reset: if the unit locks up for whatever reason, press the Reset Key to restart the player and to go back to the default setting.
3. Pre/Volume -: whilst the music is playing, a short press of this key will select the previous song, or a longer press will reduce the volume (when the music is paused, a short press will select previous song.)
4. Nex/Volume +: whilst the music is playing, a short press of this key will select the next song, or a longer press will increase the volume (when the music is paused, a short press will select next song.)




How to change your earplug




2. Take the ear bud off from the earphone



1. Select a right size of ear bud that can match your ear well




4. Put the ear bud on the earphone



3. Adjust the ear bud to right position

Hint: It is highly recommended to wear the earphone before you are in water as the ear buds can more firmly attach to your ears while they are both dry.

Armband





ILLUSTRATIONS



Step 1

Insert the player in the armband pocket



Step 2

Pull the player audio cable through the tiny hole on the armband.



Step 3

Bend the audio cable in paralell with the player and fix under the velco.



Step 4

Put it on your upper arm.



Step 5

Insert the earphone to the audio cable freely.